

Merging Technologies Ovation Media Server

Requirements

- Audio Server Interface Software Option
- Ethernet Cable

Switcher Setup

To Set Up Communications

1. Press **HOME** ⇒ **Setup** ⇒ **Installation** ⇒ **Com Setup** ⇒ **Type**.
 - Use the **Com Port** knob to select the **REMOTE X** port that you want to assign the Ovation to.
 - Use the **Device** knob to select **Audio Server**.
2. Press **Select Device**.
 - Use the **Device** knob to select **Ovation**.
3. Press **Com Type**.
 - Use the **Type** knob to select **Network TCP**.
4. Press **Com Setting**.
5. Use the **Client/Server** knob to select **Client**.
 - In the **Remote IP Address** field, enter the IP address of the Ovation.
 - In the **Remote Port** field, enter **5555**. Use this value unless told otherwise by the Merging Ovation documentation.
6. Press **HOME** ⇒ **Confirm**.

Device Setup

The Merging Ovation must have the OASIS security USB key installed.

1. Click **Settings** > **All Settings** > **ApplicationSettings** > **General** > **TCP/IP Connections**.
2. Configure one of the IP ports to the following:
 - Type: **Server**
 - IP/Name: **0.0.0.0**
 - Port: **5555**
 - Transport: **TCP**
3. Click **Settings** > **All Settings** > **ApplicationSettings** > **Controller Units** > **IP** > (the port selected in step 2).
4. Click **Enable**.
5. On the protocol list, click **Ovation Native**.

6. De-select **Send status feedback via Player selection**.
7. Click **OK**.

Compatibility

Audio Server	Version
Merging Ovation	4.04
Switchers	
Synergy 1 SD	--
Synergy Series SD	--
Synergy MD/X	--
Vision MD/X	--
Vision QMD/X	16.1a
Vision MultiPanel Support	--
Automation	
OverDrive	12.0
Port Expanders	
BSS4	✘
Control DeviceMaster	✘



